

# NanoVIP® CUBE™

**EN** NANOVIP® CUBE™ is a modern, powerful, portable network analyzer developed for professional analysis of consumption and power quality of the most complex electrical networks.

It can be used on single-phase, two-phase, three-phase (balanced and unbalanced) networks, low and medium voltage.



## MEASUREMENT PRECISION, POWERFULL ANALISYS

- ✓ Can work on networks: single-phase, two-phase, three-phase balanced with or without neutral, three-phase unbalanced with or without neutral
- ✓ Full traditional energy analysis (V, I, P, Q, S, F, PF, THD%, instantaneous values / minimum / maximum / average, energy meters absorbed and generated both three-phase for each phase).
- ✓ Analysis of power quality parameters
- ✓ The current and voltage harmonics for each phase and for the neutral up to 50°
- ✓ Imbalance of power phases
- ✓ Network outages, surges, sags Conformance testing to EN 50160
- ✓ Real measurement of the neutral current
- ✓ Display of the waveforms of currents and voltages
- ✓ 4 tariff bands setting with the related costs display
- ✓ Configuration and display of alarms on sizes 20 and settable
- ✓ Display of the time course of selectable parameters (trend)
- ✓ Automatic check of the correct connection of the implant tool
- ✓ Capable to do long-term measurement campaigns (over 24 independently, unlimited if connected to the network)
- ✓ High capacity rechargeable batteries that guaranties over 24h of work

# NanoVIP® CUBE™

## CASE:

Dimensions	203x116x53mm
Material	ABS with self-extinguishing V0 grade
Protection class	IP30
Weight	580 g

## DISPLAY:

Dimensions	68x68mm
Type	128x128 FSTN Negative dot matrix graphic LCD
Backlight	White LED
Languages	English - Spanish - Italian - German - French

## KEYPAD:

Type	Membrane keypad with 10 double-function keys
------	--

## POWER SUPPLY:

External power supply	wall-plug switching; input 100-240VAC $\pm 10\%$ 47-63Hz with interchangeable plug; output 7.5VDC - 12W
Battery pack	4 x AA NiMH 2100mAh
Duration of the battery charge	>24h (wireless off)

## CONNECTING SYSTEMS:

Systems frequencies	50Hz – 60Hz – 400Hz
Single phase	✓
Two phase	✓
Three-phase, 3-wires, balanced	✓
Three-phase, 3-wires, unbalanced	✓
4-phase, 4-wires, balanced	✓
4-phase, 4-wires, unbalanced	✓

## CONNECTIONS:

Voltages	Flexible cables L = 1.5m; 2.5mm <sup>2</sup> - 36A; 1000V CAT III - 600V CAT IV with a 4mm, 90° protected blade plug connector, crocodile clips with a 45mm opening (for sections up to 32mm) and magnetic captors
Currents	Elcontrol Energy Net interchangeable amperometric sensors
Solar radiation	-
PT100	-
Anemometer	-
Transducers	-

## FUNCTIONS:

Traditional electrical analysis	V, I, P, Q, S, F, PF, THD(V)%, THD(I)%, $\cos\phi$ , $\phi$ , peaks, minimums, maximums, averages, max. demands, etc.
Neutral current	Measured
Three phase counters	kWh, kVAh, kVAh, both absorbed that generated
Counters for each single phase	kWh, kVAh, kVAh, both absorbed that generated
Cogeneration	✓
Waveforms	V & I
Harmonics	Values and histograms up to the 50 <sup>th</sup> order
Sags	Dips, swells & interruptions
Transients	Overvoltages & overcurrents
Unbalance	✓
Test EN 50160	✓
Inrush current	✓
DC measures	✓
K factor	Up to the 25 <sup>th</sup> order
Alarms	Displayed
Alarms log	5 at display

# NanoVIP® CUBE™

Tariff bands	4
Energy costs	✓
IEC 61724 network parameters	✓
Test EN 82.25	-
OSU™ (One Shot UPS)	-
Measurement campaigns	unlimited, up to fill the memory card
<b>MEASUREMENTS:</b>	
Sampling frequency	128 samples per cycle (adaptive in 40Hz-70Hz range) 16 samples per cycle at 400Hz
Data record rate	1 sec.
Data storage rate	User selectable: 1", 5", 3", 1', 5', 15'
Type of connections available	Three-phase (3 or 4 leads), two-phase (2 leads), and single phase grid
Type of grid which can be connected	Low and medium voltage (LV and MV)
<b>VOLTAGE (TRMS)</b>	
Channels	3 channels with common neutral + 1 independent, auxiliary channel
Input impedance	4 Mohm
Scales	2
Direct measurement	Phase-phase: 7-1000VAC 40-70Hz Phase-neutral: 5-600VAC 40-70Hz Aux: 5-1000VAC 40-70Hz, 10-1400VDC
Measurement with VT	Ratio: 1-60000 Maximum value which can be displayed: 20MV
Permanent overload	Phase-phase: 1200VAC Phase-neutral: 700VAC Aux: 1200VAC, 1700VDC
Sensitivity	5VAC Phase-neutral, 7VAC Phase-phase, 10VDC
<b>CURRENT (TRMS)</b>	
Channels	5 independent channels
Input impedance	10KOhm
Scales	4
Measurement with current clamps	Ratio: 1-60000 Maximum value which can be displayed: 500KA
Sensitivity	0,2% of F.S.
<b>POWERS</b>	
Single phase power	Values < 999 GW, Gvar, GVA
Total power	Values < 999 GW, Gvar, GVA
<b>POWER COUNTERS</b>	
Maximum value before reset	99999999 kWh, kvarh, kVAh
<b>ACCURACY</b>	
<b>RMS voltages:</b>	
Scale 1	$\pm 0.25\% + 0.1\%FS^{(2)}$ @ RMS V < 350VAC <sup>(1)</sup>
Scale 2	$\pm 0.25\% + 0.05\%FS^{(2)}$ @ RMS V > 350VAC <sup>(1)</sup>
<b>RMS currents:</b>	
Scale 1	$\pm 0.25\% + 0.1\%FS^{(2)}$ @ RMS I < 5% IN clamp <sup>(1)</sup>
Scale 2	$\pm 0.25\% + 0.05\%FS^{(2)}$ @ 5% < RMS I < 20% IN clamp <sup>(1)</sup>
Scale 3	$\pm 0.25\% + 0.05\%FS^{(2)}$ @ 20% < RMS I < 50% IN clamp <sup>(1)</sup>
Scale 4	$\pm 0.25\% + 0.05\%FS^{(2)}$ @ > 50% IN clamp <sup>(1)</sup>
Power	$\pm 0.5\% + 0.05\%FS^{(2)}$
Power Factor (PF)	$\pm 0.5^\circ$
Frequency	$\pm 0.01$ Hz (40-70Hz)
Active power count (kW)	Class 0.5



# NanoVIP® CUBE™

Reactive power count (kVar)	Class 1
HARMONIC ANALYSIS	Up to 50 <sup>th</sup> order Up to 7 <sup>th</sup> at 400Hz
ANALYSIS of EN50160 parameters	
Interruptions	>500mS
Dips	>500mS
Swells	>500mS
Transient ANALYSIS	
Swells and overcurrents	>150uS
Inrush current analysis	RMS continuous sampling every 2 periods – Duration 1, 2, 5, 10 sec.
<b>COMMUNICATION:</b>	
MRH™	-
Server mode	-
Connectable MRH™ clients	-
Client mode	-
Zigbee®	-
Maximum distance outdoor	-
Maximum distance indoor	-
Mesh network	-
Wireless to PC	-
USB	to PC
<b>DATA STORAGE:</b>	
Internal memory	64kB
External memory	Micro SD (4GB included)
<b>OPERATING CONDITIONS:</b>	
Operating temperature	-10 to +55 °C
Storage temperature	-20 to +85 °C
Relative humidity	Max 95%
Maximum altitude a.s.l. (600V CAT III)	2000 m
<b>EC COMPLIANCE:</b>	
Directives	93/68/EEC (Low Voltage Electrical Equipment); 89/336/EEC and 2004/108/EC (EMC - Electromagnetic Compatibility); 2006/95/EC - 72/23/EEC (LVD - Low Voltage Directive); 2002/95/EC (RoHS - Restriction of Hazardous Substances); 2002/96/EC and 2003/108/EC (WEEE - Waste Electrical and Electronic Equipment); IEC 61724
<b>REFERENCE STANDARDS:</b>	
Safety	EN 61010-1
Electromagnetic Compatibility (EMC)	EN 61326 EN 61326/A1 EN 61326/A2 EN 61326/A3
Temperature	IEC 60068-2-1 (Operating temperature) IEC 60068-2-2 (Storing temperature)
Vibrations	IEC 60068-2-6
Humidity	IEC 60068-2-30 (Humidity)
Overload	IEC 60947-1